




G R E Y R O O S



HONNEY

a. Display



*Date position may be located at different position depends on models.

b. Setting the Time

1. Pull the crown out to the 2nd position.
Tarik tombol pemutar ke posisi 2.
2. Turn the crown to set hour and minute hands.
Putar tombol pemutar untuk mengatur waktu.
3. When the crown is pushed back to the normal position, second hand begins to run.
Kembalikan tombol pemutar ke posisi normal, jarum detik akan mulai bekerja.

c. Setting the Date

1. Pull the crown out to the 1st position.
Tarik tombol pemutar ke posisi 1.
2. Turn the crown counter-clockwise to set the date.
Putar tombol pemutar berlawanan arah jarum jam untuk mengatur tanggal.
3. After the date has been set, push the crown back to the normal position.
Setelah tanggal sudah benar, kembalikan posisi tombol pemutar ke posisi normal.

* If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change the following day.