




GREY ROOS



### a. Display



\*Date position may be located at different position depends on models.

### b. Setting the Time

1. Pull the crown out to the 2<sup>nd</sup> position.  
*Tarik tombol pemutar ke posisi 2.*
2. Turn the crown to set hour and minute hands.  
*Putar tombol pemutar untuk mengatur waktu.*
3. When the crown is pushed back to the normal position, second hand begins to run.  
*Kembalikan tombol pemutar keposisi normal, jarum detik akan mulai bekerja.*

### c. Setting the Date

1. Pull the crown out to the 1st position.  
*Tarik tombol pemutar ke posisi 1.*
2. Turn the crown counter-clockwise to set the date.  
*Putar tombol pemutar berlawanan arah jarum jam untuk mengatur tanggal.*

\* If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change the following day.

3. After the date has been set, push the crown back to the normal position.  
*Setelah tanggal sudah benar, kembalikan posisi tombol pemutar ke posisi normal.*